Installation Instructions for Clareo Wall Models CLSW-XX, & CLQW-XX



7777 N. Merrimac Ave Niles, IL 60714 T 224.333.6033 F 224.757.7557 info@luminii.com www.luminii.com


*LUMINII RESERVES THE RIGHTS TO CHANGE SPECIFICATION & INSTRUCTION WITHOUT NOTICE

Clareo Wall - Installation Instructions


Models CLSW-XX, & CLQW-XX


Please read all instructions prior to installation and keep for future reference!

- 1. Product to be installed by a qualified electrician.
- 2. Prior to installation ensure power is off at fuse box to prevent electrical shock.
- 3. Use only with Class 2 LED Driver. Utiliser seulement avec la classe 2 unite d'alimentation electrique.





- 2.1 Connect the white (neutral) & black (hot) LED driver wires to the white & black power wires (120VAC).
- 2.2 Place LED driver into the junction box.






mounting bracket. Then carefully remove the mounting bracket.









Niles, IL 60714

T 224.333.6033

F 224.757.7557

info@luminii.com

7777 N. Merrimac Ave

US

Clareo Wall - Installation Instructions

Models CLSW-XX, & CLQW-XX

Please read all instructions prior to installation and keep for future reference!

- Product to be installed by a qualified electrician.
 Prior to installation ensure power is off at fuse box to prevent electrical shock.
 Use only with Class 2 LED Driver. Utiliser seulement avec la classe 2 unite d'alimentation electrique.



7777 N. Merrimac Ave Niles, IL 60714 T 224.333.6033 F 224.757.7557 info@luminii.com www.luminii.com

Iuminii

