## LLX18-RGBW 24V - Installation Instructions

Models LLX 18-RGBW-, LLX 18X2-RGBW-

## Please read complete instruction prior to installation and keep for future reference!


- 1. Product should be installed by a qualified electrician.
- 2. Prior to installation ensure power is off at fuse box to prevent electrical shock.
- 3. Use only with Class 2 power unit. Utiliser seulement avec Classe 2 unite d'alimentation electrique.
- 4. Suitable for Damp Locations. Convient Aux Emplacements Humides.
- 5. For under-cabinet or shelf mount.
- 6. Conforms to UL STD 2108. Certified to CSA STD C22.2 No.250.0.





7777 N. Merrimac Ave Niles, IL 60714 T 224.333.6033 F 224.757.7557

info@luminii.com www.luminii.com

**Attention:** Always test LLX 18-Pixel before installing. Connect LLX 18-Pixel to power supply to ensure it is working properly and no damage has occured during shipping.







## LLX18-RGBW 24V - Installation Instructions

Models LLX 18-RGBW-, LLX 18X2-RGBW-

## Please read complete instruction prior to installation and keep for future reference!

- 1. Product should be installed by a qualified electrician.
- 2. Prior to installation ensure power is off at fuse box to prevent electrical shock
- 3. Use only with Class 2 power unit. Utiliser seulement avec Classe 2 unite d'alimentation electrique.
- 4. Suitable for Damp Locations. Convient Aux Emplacements Humides.
- 5. For under-cabinet or shelf mount.
- 6. Conforms to UL STD 2108. Certified to CSA STD C22.2 No.250.0.



by Ium
7777 N. Merrimac Ave
Niles, IL 60714
T 224.333.6033
F 224.757.7557

info@luminii.com

www.luminii.com



